



	LED	STATUS	Voltage Set Point	Action Required
AC Power LED	Green Solid	TAPS unit is functioning	13.2 volts	No Action required
	Orange Solid	TAPS unit is off	12.4 volts for 30 seconds	Start the reefer unit to bring the liftgate battery voltage above 13.2 volts
Fault LED	Orange Solid	Under voltage	9.5 volts	Charge and test the liftgate batteries. Replace batteries if necessary
	Orange Blink	Over voltage	16 volts	Test the liftgate battery charging system to determine why the voltage is reaching 16 volts
	Yellow Solid	Over power	1500 watts	Observe the device plugged into the TAPS AC outlet and make sure it does not exceed 1500 watts
	Yellow Blink	Over temperature	65 °C	Allow unit to cool to below 65 °C (149 °F). If it does not recover, contact support team
	Red Solid	System fault		Contact Purkeys at 1-800-219-1269 for assistance